




Locate the battery icon in the lower right corner of the screen. This is the notifications area. Right click on the battery icon to bring up the context menu.




Once the context menu pops up, select "Power Options" from the list.




Click the down arrow to reveal additional plans and select High Performance from the list (there should be only one additional plan listed). After the plan has been selected, click the "Change plan settings" to the right.



Click the dropdown and change the time before your computer goes to sleep to "Never". Click "Save changes" and you will automatically return to the previous window.



In the left column, click the link that says "Choose what closing the lid does".



Change the “When I close the lid” option to “Do Nothing” or “Hibernate”. If it is already set to “Do Nothing” you can leave it as it is. Click Save changes when you are finished and close the window. This should solve the intermittent Wi-Fi issues caused by your computer going to sleep.

Thank You!